

To watch TV through your projector:



1. Turn on Overhead Projector
  - a. Set input to video



2. Turn on VHS/DVD player



3. Turn on Cable Box



After everything is on, just use the Cable Box Remote Controller to change channels. You must point the remote at the cable box.

You must turn off the cable box in order for the sound to stop playing through the system.

Below is a link to Clear Picture for a channel lineup. Use the Mini-Max Converter listing. You can also explore their site for a program guide.

<http://cpiwooster.com/lineup.php>